1 2 3 4 5 6 7

LensCoat® Nikon 180-400 f/4E TC1.4 FL ED VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2, 3, 4, 5 and 6.

Piece 2

After removing the tripod mount foot slide piece 2 down below the focus ring, tapered side towards the camera. You should still be able to press the Focus Lock buttons even though they are covered.

- **Piece 3** Slide piece 3 over the focus ring.
- **Piece 4** Slide piece 4 with the window over the distance scale.
- **Piece 5** Slide piece 5 over the zoom ring.
- **Piece 6** Slide piece 6 over the rotating collar lining up the holes for the tension knob, lens foot and straps.

Piece 7

Piece 7 has a small hole to accommodate for the filter knob. Carefully slide and stretch piece 7 over the last segment of the lens without putting too much stress on the hole itself. Line up the AF/VR switch bank with the long window and the 1.4 teleconverter with the smaller window.

For final placement, pull the windows slightly away from the lens and adjust to the left or right.

**You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this be careful as it is easy to destroy the window.

LensCoat.com® 80 Throckmorton Street Freehold, NJ 07728