



LensCoat® Nikon 200VR INSTRUCTIONS

Piece 1 - Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a ¼ inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the rotating lens collar. This piece can also be put on by sliding down the lens and around the lens foot.

Piece 3

Carefully slide it down the lens aligning the focus scale, focus mode and limiting switches. **For final placement, pull the distance scale window slightly away from the lens and adjust to the left or right. **You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this, be careful as it is easy to destroy the window**

Rotating Lens Collar

The LensCoat® Nikon 200VR lens cover kit includes two strips of neoprene with adhesive tape applied to the back. One is for the lens collar and one can be used for the VR slide switch. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728