

LensCoat® Tamron 150-600 G2 INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Piece 2

Remove rotating collar for easy placement stretch and slide piece 2 down the lens to just after the zoom ring.

Piece 3

With the rotating collar removed, slide piece 3 down the lens to the zoom ring.

Piece 4

With rotating collar removed carefully slide piece 4 it down the lens just after the focus ring. Lining up the hole for the zoom lock.

Piece 5

With rotating collar removed carefully slide piece 5 it down to the focus ring.

Piece 6

With rotating collar removed carefully slide piece 6 it down the lens lining up the distance window and AF controls. For final placement pull the window for the slightly away from the lens and adjust to the left or right.

*if you are not using the rotating collar then use the larger 6b for the last section of the lens and omit 7.

Piece 7

Put the rotating collar on. Slide on piece 7 by aligning the alignment hole with white alignment mark on the lens. If you are not using the rotating collar then use piece 6B instead.

Rotating Lens Collar

The LensCoat[®] Tamron 150-600 lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

Zoomed Lens Barrel

The LensCoat[®] Tamron 150-600 lens cover kit includes an optional piece that can be affixed to the lens via the Velcro strip ONLY when the lens is fully extended

LensCoat.com[®] 80 Throckmorton Street Freehold, NJ 07728