

LensCoat[®] Nikon 80-400 VR AF-S INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the zoom ring.

Remove the tripod mount foot / rotating lens collar from the lens. This will allow for easy installation of the remaining pieces.

Piece 3

Slide piece 3 over the lens and position it on the zoom ring.

Piece 4

Slide piece 4 over the lens and position it over the distance scale / AF controls. For final placement pull the window slightly away from the lens and adjust to the left or right.

Piece 5

Slide piece 5 over the lens and position it on the focus ring.

Piece 6

Optional piece if you are not using the rotating lens collar. If you are using the collar than this piece is not used. Slide piece 6 on the last section of the lens.

Zoomed Lens Barrel

The LensCoat[®] 80-400 VR AF-S lens cover kit includes an optional piece that can be affixed to the lens via the Velcro strip ONLY when the lens is fully extended

Rotating Lens Collar

The LensCoat[®] Nikon 80-400 VR AF-S lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cut out the desired length for the parts of the lens collar you want to cover. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com[®] 80 Throckmorton Street Freehold, NJ 07728