



## **LensCoat® Tamron 150-500mm f/5-6.7 Di III VC VXD** **INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

### ***Piece 2***

Stretch and slide piece 2 down the lens to the zoom ring.

### ***Piece 3***

Slide piece 3 down the lens to between the zoom and focus ring with the window lining up the distance scale window and AF/MF controls and the lock switch. **For final placement pull the window for the slightly away from the lens and adjust to the left or right.**

### ***Piece 4***

Slide piece 4 it down the lens to the focus ring.

### ***Piece 5***

Slide piece 5 on the last segment of the lens.

**When using the rotating lens collar use pieces 5A**

### ***Piece 5A***

Slide piece 5 on the last segment.

### ***Zoom Sleeve***

The LensCoat kit for the Tamron 150-500 includes an optional sleeve to cover the barrel that would be exposed when zooming. With the lens shade off carefully stretch the smaller side elastic over the front of the lens onto piece 2 and then the larger side onto the lens, put the lens hood on and pull the larger side elastic up onto the hood, position both sides where comfortable. As you zoom in the sleeve will stretch and when it's zoomed out it will slightly bunch up.

### ***Rotating Lens Collar***

The LensCoat® kit for the Tamron 150-500 a strip of neoprene with adhesive tape applied to the back. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728