

# LensCoat<sup>®</sup> Nikon 500mm AF-I INSTRUCTIONS

#### Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a <sup>1</sup>/<sub>4</sub> inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

#### Piece 2

Slide piece 2 down below the focus ring, at the end of the lens.

### Piece 3

Slide piece 3 down to the focus ring, tapered side towards the camera. You could carefully loop piece 3 around the foot or you could very carefully stretch piece 3 over the front of the lens being careful not to put too much pressure on the seam.

### Piece 4- Distance Scale Window

Slide piece 4 down to the before the focus ring lining up the distance scale window. You could carefully loop piece 4 around the foot or you could very carefully stretch piece 4 over the front of the lens being careful not to put too much pressure on the seam.

### Piece 5

Slide piece 6 down to the before the focus ring lining up the hole for the AF/M focus setting button. You could carefully loop piece 5 around the foot or you could very carefully stretch piece 5 over the front of the lens being careful not to put too much pressure on the seam.

### Piece 6

Slide piece 6 down to just after the rotating collar/lens foot. You could carefully loop piece 6 around the foot or you could very carefully stretch piece 6 over the front of the lens being careful not to put too much pressure on the seam.

## Piece 7

Carefully slide piece 7 down lining up the distance limit switch window and hole for the filter knob.

### Piece

Slide piece 8 over the aperture ring.

#### **Rotating Lens Collar**

The LensCoat<sup>®</sup> Nikon 500 AF-I lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com<sup>®</sup> 80 Throckmorton Street Freehold, NJ 07728