



LensCoat® Nikon Z 100-400mm f/4.5-5.6 VR S INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Remove the lens foot for easier placement of the sections-

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to the zoom ring. This piece can also be put on by looping it around the lens foot and sliding down the lens.

Piece 3

Slide piece 3 over the lens to between zoom and focus ring. You can feel the buttons through fabric.

Piece 4

Slide piece 4 over the lens to the focus rings.

Piece 5

Slide piece 5 over the lens aligning the window for the display. You can feel the buttons through fabric.

Piece 6

Slide piece 6 over the control ring.

Piece 7

Slide piece 7 over the lens to the rotating collar aligning the hole for the tension knob and elastic on either side of the lens foot base.

Piece 8

Slide piece 8 over the last section aligning the window over AF/M and limiter switches.

Zoom Sleeve

The LensCoat kit for the Nikon Z 100-400 includes an optional sleeve to cover the barrel that would be exposed when zooming. With the lens shade off stretch the elastic over the front of the lens onto piece 2 and then the other side onto the lens, put the lens hood on and pull the elastic up onto the hood, position both sides where comfortable. As you zoom in the sleeve will stretch and when it's zoomed out it will slightly bunch up.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728