



## **LensCoat® Pentax 560mm INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Carefully slide and stretch the lens cover into place over the lens shade.

### ***Piece 2***

Remove foot from rotating collar for easy placement, stretch and slide piece to just below rotating lens collar.

### ***Piece 3***

Carefully slide piece 3 to the focus ring.

### ***Piece 4***

Slide on piece 4 by aligning the window for the distance scale window and slits for lens strap.

### ***Piece 5***

Slide on piece 5 lining up the hole for the lens filter.

### ***Piece 6***

Slide on piece 6 onto the last segment of the lens.

### ***Rotating Lens Collar***

The LensCoat® Pentax 560 lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

### ***Velcro Piece-***

Included with your LensCoat kit is an optional piece for the lens barrel when the lens shade is slid forward. It is easily put on and removed with the Velcro closure.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728