



LensCoat® Sony FE 600 f4 GM OSS INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood-locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2, 3, 4,5. You can also put sections 2,3,4,5 and 6 on by looping the pieces around the lens foot and over the top of the lens where it mounts to the camera.

Piece 2

After removing the tripod mount foot slide piece 2 down below the focus recall ring, tapered side towards the camera.

Piece 3

Slide piece 3 down to the focus recall ring after focus ring.

Piece 4

Slide piece 4 down to the focus ring

Piece 5

Slide piece 5 down just before the focus ring.

Piece 6

Slide piece 6 over the rotating collar lining up the holes for the tension knob, lens foot and straps.

Piece 7- AF/OSS

Slide piece 8 on by **carefully lining up the AF/OSS windows and slide into. For final placement pull the window slightly away from the lens and adjust to the left or right.**

****you should be able to slide the controls through the plastic window with your finger, some people like to punch small holes in the plastic to allow for easier access, if you choose to do this be careful as it is easy to destroy the window.**

Piece 8

Slide piece 8 over the last section lining up the hole with the filter knob.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728