

1 2 3 4 5 6 7



## **LensCoat® Canon 200-400 f/4 IS INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood-locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2, 3, 4, 5. You can also put sections 2, 3, 4 and 5 on by looping the pieces around the lens foot and over the top of the lens where it mounts to the camera.

### ***Piece 2***

After removing the tripod mount foot slide piece 2 down below the focus recall ring, tapered side towards the camera.

### ***Piece 3***

Slide piece 3 down to the focus ring.

### ***Piece 4***

Slide piece 4 down to just above the focus ring.

### ***Piece 5- IS and Distance Scale window***

Slide piece 5 on by **carefully lining up the IS and distance scale windows and slide into place being careful not to get the plastic windows caught on the rotating collar knob or strap attachment. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.** **\*\*you should be able to slide the controls through the plastic window with your finger, some people like to punch small holes in the plastic to allow for easier access, if you choose to do this be careful as it is easy to destroy the window.**

### ***Piece 6***

Slide piece 6 over the teleconverter section.

### ***Piece 7***

Carefully slide it down the lens aligning the AF/MF switches. **For final placement, pull the distance scale window slightly away from the lens and adjust to the left or right.**

### ***Rotating Lens Collar***

The LensCoat® Canon 200-400 f/4 IS lens cover kit includes a strip of neoprene with adhesive tape applied to the back. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728