



## **LensCoat® Tamron 200-500 INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

### ***Piece 2***

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the zoom ring.

### ***Piece 3***

Remove rotating collar or loop piece 3 over the lens foot around the back of the lens to the zoom ring. **For final placement pull the lock switch window slightly away from the lens and adjust to the left or right.**

### ***Piece 4***

Slide piece 4 down the lens to just before the tripod collar.

### ***Piece 5***

Depending on what mount lens you have (ie Canon/Nikon) piece 5 may not be needed. Slide on piece 5 by aligning the hole with the alignment dot.

### ***Rotating Lens Collar***

The LensCoat™ Tamron 200-500 lens cover kit includes an optional strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cut the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

### ***Velcro Piece-***

Included with your LensCoat kit is an optional piece if you find yourself shooting extensively with the lens fully zoomed. It is easily put on and removed with the Velcro closure.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728