

# LensCoat® Nikon 800 VR INSTRUCTIONS

## Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a ¼ inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod foot from the rotating lens collar. This will allow for easier installation of the pieces.

### Piece 2

Slide piece 2 down to the end of the lens.

#### Piece 3

Slide piece 3 down to the focus ring.

### Piece 4 VR and Distance Scale window

Slide piece 4 on by carefully lining up the VR and distance scale windows and slide into place being careful not to get the plastic windows caught on the rotating collar knob or strap attachment. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.

## Piece 5

Slide on piece on the rotating collar lining up the slits for the lens strap and hole lens foot.

#### Piece 6

Slide on piece 6 onto the last section. There is a small hole for the filter knob and a slits for the latches. Be extra careful when putting this piece on not putting too much stress on the holes and slit.

# 1.25 teleconverter

The LensCoat® Nikon 800VR lens cover kit includes a small cover for the 1.25 teleconveter

LensCoat.com® 80 Throckmorton Street Freehold, NJ 07728