



LensCoat® Nikon 600VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood covers from the lens. Piece 1 has a ¼ inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Piece 2- Lens Hood Cover 2

Piece 2 has a ¼ inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Piece 3

With the lens hood removed stretch and slide piece 3 down from the glass to just above the rotating collar, tapered side towards the camera.

Piece 4

Slide piece 4 down the lens and just after the focus ring and before the rotating collar.

Piece 5

Slide piece 5 down the lens to the focus ring

Piece 6

Slide piece 5 down the lens and just before the focus ring aligning the AF controls, limiting switches and distance scale.

****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this, be careful as it is easy to destroy the window.**

Piece 7

Carefully slide piece 6 down the lens, there is a small hole for the filter knob and a slit for the strap. **Be extra careful when putting this piece on. Do not put too much stress on the holes and slit.**

Rotating Lens Collar

The LensCoat® Nikon 600VR lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the lens collar. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done, remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728