

LensCoat® Sony 70-400 INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the zoom ring.

Piece 3

Remove rotating collar for easy placement or loop piece 3 over the lens foot around the back of the lens, to the zoom ring.

Piece 4

With rotating collar removed or by looping over the lens foot and around the back of the lens and carefully slide piece 4 it down the lens just after the focus ring. For final placement pull the window slightly away from the lens and adjust to the left or right.

Piece 5

With rotating collar removed or by looping over the lens foot and around the back of the lens and carefully slide piece 5 it down the lens just after the rotating collar. For final placement pull the window slightly away from the lens and adjust to the left or right.

Piece 6

Slide on piece 6 by aligning the window for the distance scale. For final placement pull the window slightly away from the lens and adjust to the left or right.

Rotating Lens Collar

The LensCoat[®] Sony 70-400 lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

Zoomed Lens Barrel

The LensCoat[®] Sony 70-400 lens cover kit includes an optional piece that can be affixed to the lens via the Velcro strip ONLY when the lens is fully extended

LensCoat.com[®] 80 Throckmorton Street Freehold, NJ 07728