



## **LensCoat® Olympus 300 f4 IS INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Carefully slide and stretch the lens cover into place over the extendable lens hood and on lens barrel. The lens hood cover is designed to slide over the barrel when the hood is extended. It should slide back easy too. If when retracting the hood the cover seems to stick or buckle just rotate the hood slightly while retracting.

Remove the tripod mount foot / rotating lens collar. This will allow for easy installation of the other pieces.

### ***Piece 2***

With the tripod mount foot / rotating collar removed, slide piece 2 down to the focus ring.

### ***Piece 3***

With the tripod mount foot / rotating collar removed, slide piece 3 down to above the focus ring lining up the window over the AF controls.

### ***Piece 4***

This piece is only used when the rotating collar is not in use. You can either slide this piece on over the DR cover or on the lens itself without the cover.

### ***Piece 5***

Slide piece 5 on the last segment of the lens aligning the hole with the alignment dot

### ***Rotating Lens Collar and AF control***

The LensCoat® Olympus 300 f4 IS lens cover kit includes a strip of neoprene with adhesive tape applied to the back. Cutout the desired length for the lens collar. After the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728