



LensCoat® Nikon 300 f4 AFS INSTRUCTIONS

Piece 1- Lens Hood Cover

Carefully slide and stretch the lens cover into place over the extendable lens hood and onto the lens barrel. The lens hood cover is designed to slide over the barrel when the hood is extended. It should slide back easily too. If when retracting the hood the cover seems to stick or buckle, just rotate the hood slightly while retracting.

Remove the tripod mount foot / rotating lens collar. This will allow for easy installation of piece 2.

Piece 2

After removing the tripod mount foot / rotating collar, slide piece 2 down to just above the focus ring, lining up the distance scale and AF controls.

Rotating Lens Collar

The LensCoat® Nikon 300 f4 AFS lens cover kit includes one strip of neoprene with adhesive tape applied to the back. Cut the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728