



LensCoat® Nikon 70-200VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the focus ring, lining up the window with the distance scale. This piece can also be put on by looping it around the lens foot and sliding down the lens or remove the lens foot. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

Piece 3

Loop piece 3 over the lens foot around the back of the lens and onto the focus ring.

Piece 4

Loop piece 4 over the lens foot around the back of the lens and just past the zoom ring and before the focus ring.

Piece 5

Loop piece 5 over the lens foot around the back of the lens and onto the zoom ring.

Piece 6

Loop piece 6 over the lens foot and around the back of the lens and carefully slide it down the lens aligning the focus mode and limiting switches. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this be careful as it is easy to destroy the window.**

Piece 7

Slide on piece 7 by lining up the hole to the lens mount mark (white line) on the lens being careful not to pull/stretch the hole too much to prevent tears.

Rotating Lens Collar

The LensCoat® Nikon 70-200VR lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728