

LensCoat® Sigma 18-35mm f/1.8 DC HSM Art Lens INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Piece 2

Slide piece 2 down to the focus ring.

Piece 3- AF/MF and Distance scale window

Slide piece 3 on by **carefully lining up the AF/MF control and distance scale windows and slide into place. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.**


Piece 4

Slide piece 4 down to the zoom ring

Piece 5

Slide piece 5 the last segment lining up the alignment dot.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728



LensCoat® Sigma 18-35mm f/1.8 DC HSM Art Lens INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Piece 2

Slide piece 2 down to the focus ring.

Piece 3- AF/MF and Distance scale window

Slide piece 3 on by **carefully lining up the AF/MF control and distance scale windows and slide into place. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.**

Piece 4

Slide piece 4 down to the zoom ring

Piece 5

Slide piece 5 the last segment lining up the alignment dot.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728