



## **LensCoat® Fuji XF 200 f/2 R LM OIS WR w 1.4x TC INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Piece 1 has a notch at one end of the cover to accommodate for the lens hood-locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the notch. \*There is no cutout for the polarizing filter. If you choose to cut out a section, we suggest that you try to round the corners as to help prevent tears.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2-6. You can also put sections 2-6 on by looping the pieces around the lens foot and over the top of the lens where it mounts to the camera. When looping the pieces around the lens foot remember to invert them so they have the correct orientation once flipped over the lens.

### ***Piece 2***

Stretch and slide piece 2 down the lens to just after the focus ring.

### ***Piece 3***

Slide piece 3 down the lens to the focus ring.

### ***Piece 4***

Carefully slide piece 4 it down the lens just before the focus ring and after the aperture ring.

### ***Piece 5***

Slide piece 5 it down to the aperture ring.

### ***Piece 6***

Carefully slide piece 6 it down the lens lining up the Window for and AF/OS controls. **For final placement pull the window for the slightly away from the lens and adjust to the left or right.**

### ***Piece 7***

Slide the elastic around the rotating collar lining up the hole for the tension and the cut out for the lens strap.

### ***Piece 8***

Slide on piece 8 by aligning the alignment notch with the alignment mark on the lens.

### **Piece 9 1.4x TC**

Place the cut out for the teleconverter release on the extender release and carefully slide and stretch the cover into place over the teleconverter. **Be careful not to put too much stress on the piece around the hole.**