



LensCoat® Nikon 70-200 f2.8 FL VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the zoom ring. This piece can also be put on by looping it around the lens foot or removing the lens foot and sliding down the lens.

Piece 3

Loop piece 3 over the lens foot around the back of the lens and onto the zoom ring.

Piece 4

Loop piece 4 over the lens foot and around the back of the lens and carefully slide it down the lens between the focus and zoom ring

Piece 5

Loop piece 5 over the lens foot around the back of the lens and onto the focus ring.

Piece 6

Loop piece 6 over the lens foot and around the back of the lens and carefully slide it down the lens aligning the distance scale and focus mode/VR /limiting switches. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

Piece 7a

When lens foot is on the lens use 7a sliding on the last section of the lens and lining up the notch to the white alignment.

Piece 7b

Used when lens foot is removed. Position the rotating collar so the small white dot is in line with the alignment dot. Slide on piece 7b lining up the notch to the lens mount the hole for the rotating collar screw.

Rotating Lens Collar

The LensCoat® Nikon 70-200 FL lens cover kit includes an optional strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728