



LensCoat® Canon 24-70 f2.8 IS II INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Piece 2

Slide piece 2 down the lens to just after the focus ring.

Piece 3

Slide piece 3 down the lens to the focus ring.

Piece 4- AF and Distance scale window

Slide piece 4 on by **carefully lining up the AF and distance scale windows and slide into place. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.**

Piece 5

Slide on piece 5 on the zoom ring.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728