



---

## **LensCoat® Canon 300 f4 IS INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Carefully slide and stretch the lens cover into place over the extendable lens hood and on lens barrel. The lens hood cover is designed to slide over the barrel when the hood is extended. It should slide back easy too. If when retracting the hood the cover seems to stick or buckle just rotate the hood slightly while retracting.

Remove the tripod mount foot / rotating lens collar. This will allow for easy installation of piece 2.

### ***Piece 2***

After removing the tripod mount foot / rotating collar, slide piece 2 down to just above the focus ring lining up the distance scale and IS controls.

### ***Rotating Lens Collar and AF control***

The LensCoat® Canon 300 f4 IS lens cover kit includes two 10½ inch strip of neoprene with adhesive tape applied to the back. Cutout the desired length for the parts of the lens collar and AF / distance limiting section you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728