



LensCoat® Canon 70-200IS f2.8 II INSTRUCTIONS

Focus & Zoom ring

Two optional pieces have been included if you would like to cover the zoom and focus rings. If so then one goes between piece 2 and 3 and the other between 3 and 4.

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the focus ring.

Remove the tripod mount foot / rotating lens collar from the lens. This will allow for easy installation of piece 3 or put on piece 3 first from the glass and then piece 2 if you do not want to remove the rotating collar.

Piece 3

Slide piece 3 over the lens and position it in between the zoom ring and the focus ring. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this be careful as it is easy to destroy the window**

Piece 4

Slide on piece 4 by lining up the 1/8 hole to the lens mount mark (red dot) on the lens being careful not to pull/stretch the hole too much to prevent tears.

Rotating Lens Collar

The LensCoat® Canon 70-200IS f2.8 lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cut out the desired length for the parts of the lens collar you want to cover. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728