



LensCoat® Canon RF 100-300 f2.8 L IS INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Remove rotating collar foot for easier placement of piece 2-7

Piece 2

Stretch and slide piece 2 down the lens to the front of the lens.

Piece 3

Slide piece 3 down the lens to the control ring.

Piece 4

Slide piece 4 down the lens to the focus ring.

Piece 5

Slide piece 5 down the lens to the zoom control ring.

Piece 6

Slide piece 6 on to just before the tension ring lining up the window for the AF/IS controls. **For final placement pull the window for the slightly away from the lens and adjust to the left or right.**

Piece 7

Slide piece 7 on by lining up the hole to the rotating collar adjustment and slits for the straps and place the elastic around the lens foot being careful not to pull/stretch the hole too much to prevent tears.

Piece 8

Slide piece 8 on to the rear section of the lens.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728