



LensCoat® Pentax 150-450 INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Piece 2

Remove rotating collar foot for easy placement. Stretch and slide piece 2 down from the glass to just above the zoom ring.

Piece 3

Stretch and slide piece 3 over the lens to the zoom ring.

Piece 4

Carefully slide piece 4 it down the lens just after the focus ring lining up the window for the AF controls and the lock switch. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

Piece 5

Carefully slide piece 5 it down to the focus ring.

Piece 6

Slide piece 6 it down the lens just after the rotating collar lining up the distance scale window. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

Rotating Lens Collar

The LensCoat® Pentax 150-450 lens cover kit includes a strip of neoprene with adhesive tape applied to the back for the rotating lens collar. Cutout the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

Zoomed Lens Barrel

The LensCoat® Pentax 150-450 lens cover kit includes an optional piece that can be affixed to the lens via the Velcro strip **ONLY** when the lens is fully extended

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728